UNDERCOVER LED KIT USER MANUAL

CONTENTS

LIGHTHEAD x 2pcs

EXTENSION CABLE

FLASHER & CABLE

GASKET x 2pcs

FLANGE OPTION x 2pcs













SCREW x 4pcs

FOAM x 2pcs

LIGHT ASSEMBLY INSTALLATION

- 1. Remove the Corner/Head/Tail light from vehicle.
- 2. Select location to mount lighthead.
- 3. Drill 1 inch diameter hole to the light assembly.
- 4. Insert lighthead into hole and rotate to achieve optimum effect.
- 5. Secure lighthead with supplied sheet metal screws.
- 6. Apply silicone (user-supplied) for better seal.

WARNING: Do NOT cover heat sink with silicone. It may cause damage to the product and void warranty.

OPERATIONS

To +VDC (fuse @2A) for Color1 activationRED	. ——
To Chassis GroundBLACK	
To +VDC (fuse @2A) for Color2 activationWHITE	
For Synchronization & Flash PatternsYELLOW Connect YELLOW wires of all Kits together for synchronization *All kits must be set at the same pattern	
F 0: # 0 !!(F 1 / : 1 1 1)	


For Simultaneous or Split Flash (single head):

- 1. Apply +VDC to RED and YELLOW wires simultaneously to enter Mode selection; lighthead will display single flash.
- 2. Remove YELLOW wire from +VDC and momentarily apply to +VDC to change Mode: Mode1 = Simultaneous Flash, Color1 and Color2 LEDs flash together.

 Mode2 = Split Flash, Color1 LEDs alternate with Color2 LEDs.

Mode1 (Simultaneous Flash)		DI I	Head1	Head2	
(Suitable for Single-Color Heads)		Flash	Color1Color2	Color1Color2	
Flash Patterns #1~9	Color1&2 flash together, Head1 alternate Head2	1st 2nd	on on off off	off off on on	
Flash Patterns #10~17	Color1&2 flash together, Head1&2 flash together	1st 2nd	on on off off	on on off off	
Flash Pattern #18	Steady Half	1st 2nd	on on on	on on off off	

Mode2 (Sp (Suitable fo	lit Flash) or Split-Color Heads)	Flash	Head1 Color1Color2	Head2 Color1Color2
Flash Patterns #1~9	Color1 alternate Color2	1st 2nd	on off off on	off on off
Flash Patterns #10~17	Color1 flash together, Color2 flash together	1st 2nd	on off off on	on off off on
Flash Pattern #18	Steady Half	1st 2nd	on on off	on on off



For Flash Pattern change, momentarily apply +VDC to YELLOW wire:

· once for next pattern

· quickly three times for reset


Flash Patterns			
1	Random	11	Double (all)
2	Single (split)	12	Quad (all)
3	Double (split)	13	Quint (all)
4	Quad (split)	14	Mega (all)
5	Quint (split)	15	Ultra (all)
6	Mega (split)	16	Single-Quad (all)
7	Ultra (split)	17	Single H/L (all)
8	Single-Quad (split)	18	Steady Half
9	Single H/L (split)	19	Steady All
10	Single (all)		

NOTE: This unit may not be factory set at FP# 1.


FLANGE MOUNT INSTALLATION (for kits with Flange option only)

- 1. Use mounting flange to mark wire and screws holes to drill.
- 2. Drill marked holes accordingly.
- 3. Insert lighthead pigtail into wire hole.
- 4. Place foam, lighthead, and flange in line with the mounting holes, and secure with supplied sheet metal screws.

NOTE: Position lighthead so that LEDs are facing the desired direction.



WARNING: Make sure to use the foams when mounting lightheads.



WIRING TO EXISTING STROBE CABLES

In this configuration, existing strobe extension cables are used to facilitate installation.

