




PRISE EN MAIN RAPIDE / QUICK GUIDE


BOITIER DE COMMANDES HANDY RAMPE FX SPA DEFILEMENT
SCROLLING SPA FX LIGHTBAR HANDY CONTROL PANEL

FONCTIONS




- + = FONCTION CRUISE / CRUISE FUNCTION
- + = CHANGEMENT DE TONALITE / TONE SWITCH
- + = ACTIVATION & DESACTIVATION FEUX DE PENETRATION / GRILL LAMP ACTIVATION & DEACTIVATION
- + = ACTIVATION & DESACTIVATION RADIO BROADCASTING / RADIO BROADCASTING ACTIVATION & DEACTIVATION
- + = ACTIVATION & DESACTIVATION ECLAIRAGE TEXTE / TEXT LIGHT SWITCHING ON & SWITCHING OFF
- + = ENREGISTREMENT MESSAGES AUDIO / AUDIO MESSAGES RECORDING

MARCHE / ON



OU / OR




ARRÊT / OFF



OU / OR



OU / OR



DIFFUSION DE LA VOIX / VOICE BROADCASTING



DIFFUSION DE MESSAGE ENREGISTRE / RECORDED MESSAGE BROADCASTING

MESSAGE 1



MESSAGE 2




MESSAGE 3



STOP



ENREGISTREMENT MESSAGE / MESSAGE RECORDING



SELECTION MESSAGE

STOP

MESSAGE SELECTION

DOCUMENTS COMPLETS SUR NOTRE SITE INTERNET

