
















### PRISE EN MAIN RAPIDE / QUICK GUIDE


BOITIER DE COMMANDES HANDY RAMPE FX SPA DEFILEMENT  
SCROLLING SPA FX LIGHTBAR HANDY CONTROL PANEL

#### FONCTIONS




-  +  = FONCTION CRUISE / CRUISE FUNCTION
-  +  = CHANGEMENT DE TONALITE / TONE SWITCH
-  +  = ACTIVATION & DESACTIVATION FEUX DE PENETRATION GRILL LAMP ACTIVATION & DEACTIVATION
-  +  = ACTIVATION & DESACTIVATION RADIO BROADCASTING / RADIO BROADCASTING ACTIVATION & DEACTIVATION
-  +  = ACTIVATION & DESACTIVATION ECLAIRAGE TEXTE / TEXT LIGHT SWITCHING ON & SWITCHING OFF
-  +  = ENREGISTREMENT MESSAGES AUDIO / AUDIO MESSAGES RECORDING

#### MARCHE / ON



OU / OR




#### ARRÊT / OFF




OU / OR




OU / OR




## DIFFUSION DE LA VOIX / VOICE BROADCASTING



## DIFFUSION DE MESSAGE ENREGISTRE / RECORDED MESSAGE BROADCASTING



## ENREGISTREMENT MESSAGE / MESSAGE RECORDING



DOCUMENTS COMPLETS SUR NOTRE SITE INTERNET

