

STANDBY®

When attention matters.

MCS-NX-8 INSTALLATION GUIDE



10R-0213006

C-10747-A_MDX00068_HW03/25

CONTENTS

Pre-Installation & Required Tools	4
1.1) Crimping Tool.....	4
1.2) Replacement Pins.....	4
1.3) Connector Receptacles.....	4
1.4) MHE Replacement Connector Pack	5
2.1) Installation Requirements	6
2.2) Mounting.....	7
3.1) Wiring	8
3.1.1) GPS	8
3.1.2) SPKR -Siren Output (S1 and S2).....	8
3.1.3) PWR - Power Connection.....	8
3.1.4) GND - Power Ground	8
3.1.5) Connector A - High Power Outputs.....	9
3.1.6) Connector B- Low Power Outputs.....	9
3.1.7) Connector C - Aux Connector	9
3.1.8) HANDSET/CAN1 - System Connector	10
3.1.9) CAN3\RS485 Connector	10
3.1.10) USB-C (Micro Rev1).....	10
3.1.11) CAN2 Connector	10
3.1.12) RST - Reset Button	10
3.1.13) SEL - Select Button	10
3.1.14) DIP SELECT - CAN Termination.....	10
3.1.15) SD – SD card slot.....	10
5.1) Version History	11

Table of Figures

Figure 1 Dimensions and Mounting holes 7
Figure 2 Connector Layout 8

Pre-Installation & Required Tools

1.1) **Crimping Tool**

Universal Molex Crimp Tool.

Molex part number: 0638111000

- <http://www.digikey.co.uk/> Part Number: WM9999-ND
- <http://www.mouser.co.uk> Part Number: 538-63811-1000
- <http://uk.rs-online.com/> Part Number: 710-6499
- <http://www.ttieurope.com> Part Number: 63811-1000

Anderson PowerPole Crimp Tool

Anderson part number: 1309G4

- <http://www.digikey.co.uk/> Part Number: 2243-1309G4-ND
- <http://www.mouser.co.uk> Part Number: 879-1309G4

1.2) **Replacement Pins**

Mini Fit Female 50-34-8582 or 0039000211

- <http://www.digikey.co.uk/> Part Number: 0050348582-ND or WM14176CT-ND
- <http://www.mouser.co.uk> Part Number: 538-50-34-8582

Mega Fit Female 768230322

- <http://www.digikey.co.uk/> Part Number: WM11982TR-ND
- <http://www.mouser.co.uk> Part Number: 538-76823-0322

Anderson PP75 - 5900

- <http://www.digikey.co.uk/> Part Number: 2243-5900-ND
- <http://www.mouser.co.uk> Part Number: 879-5900

1.3) **Connector Receptacles**

Mini Fit Male 3-Way 39014031

- <http://www.digikey.co.uk/> Part Number: WM23608-ND
- <http://www.mouser.co.uk> Part Number: 538-39-01-4031

Mini Fit Male 8-Way 39012080

- <http://www.digikey.co.uk/> Part Number: WM3703-ND
- <http://www.mouser.co.uk> Part Number: 538-39-01-2080

Mini Fit Male 4-Way 39013042

- <http://www.digikey.co.uk/> Part Number: WM1022-ND
- <http://www.mouser.co.uk> Part Number: 538-39-01-3042

Mini Fit Male 6-Way	39012060
• http://www.digikey.co.uk/	Part Number: WM3702-ND
• http://www.mouser.co.uk	Part Number: 538-39-01-2060
Mini Fit Male 14-Way	39012140
• http://www.digikey.co.uk/	Part Number: WM3706-ND
• http://www.mouser.co.uk	Part Number: 538-39-01-2140
Mega Fit Male 2-Way	171692-0102
• http://www.digikey.co.uk/	Part Number: WM10385-ND
• http://www.mouser.co.uk	Part Number: 538-171692-0102
Mega Fit Male 4-Way	171692-0104
• http://www.digikey.co.uk/	Part Number: WM10386-ND
• http://www.mouser.co.uk	Part Number: 538-171692-0104
Anderson PP75	5916G7-BK
• http://www.digikey.co.uk/	Part Number: 2243-5916G7-BK-ND
• http://www.mouser.co.uk	Part Number: 879-5916G7-BK

1.4) ***MHE Replacement Connector Pack***

2022020	MCS-NX-8 Pins and Connector Pack
2022020-S	MCS-NX-8S Pins and Connector Pack

2.1) **Installation Requirements**

- 2.1.1) Each power connector (Anderson PowerPole) must be fused with a fuse rated to 40A or less.
- 2.1.2) DO NOT obstruct fan vents along the side of the MCS-NX-8. Do not install any equipment on top or underneath the MCS-NX-8.



- 2.1.3) The MCS system uses 6 pin RJ11 connectors and the MCS-NX uses RJ45 8 pin connectors, they utilize the same handsets and external CAN devices. Make sure you do not insert a RJ11 6 pin connector into the RJ45 8 way port. This will damage the pins and cause the CAN1 to go faulty on that connector. The above label is placed over the RJ45 connector on the MCS-NX to avoid this.



- 2.1.4) When connecting the power supply to the MCS-NX unit please ensure that the red connectors are seated correctly to avoid causing operational issues. For a short demonstration video click on the image above or go to <https://www.youtube.com/shorts/nryPMNy-Mcc> .

The above installation requirement must be followed for safe operating and extended product lifetime

Mounting




Figure 1 Dimensions and Mounting holes

4 x M4 holes are supplied for mounting the unit to a base panel.

3.1) **Wiring**




Figure 2 Connector Layout

3.1.1) **GPS**

Pin	Name	Function
1	GPS	Connection for Active Antenna for GPS function (designated by G1)

3.1.2) **SPKR -Siren Output (S1 and S2)**

Pin	Name	Function
1	2A-	Speaker 2 Channel A Negative Output
2	2B-	Speaker 2 Channel B Negative Output
3	1A-	Speaker 1 Channel A Negative Output
4	1B-	Speaker 1 Channel B Negative Output
5	2A+	Speaker 2 Channel A Positive Output
6	2B+	Speaker 2 Channel B Positive Output
7	1A+	Speaker 2 Channel A Positive Output
8	1B+	Speaker 2 Channel B Positive Output

3.1.3) **PWR - Power Connection**

Pin	Name	Function
1	Supply	12-24V supply

3.1.4) **GND - Power Ground**

Pin	Name	Function
1	Ground A	Chassis ground
2	Ground B	Chassis ground

3.1.5) Connector A - High Power Outputs

Pin	Name	Function
1	High Power Output 1	User Defined High Power Output (Positive Switched 20A)*Note1
2	High Power Output 2	User Defined High Power Output (Positive Switched 20A)*Note1
3	High Power Output 3	User Defined High Power Output (Positive Switched 20A)
4	High Power Output 4	User Defined High Power Output (Positive Switched 20A)

Note 1 : HP1 and HP2 can be combined to achieve 30A by wiring HP1 and HP2 to the load in parallel. This is enabled in the configuration software.

3.1.6) Connector B- Low Power Outputs

Pin	Name	Function
1	Low Power Output 5	User Defined Low Power Outputs (Positive or Negative 2.4) *Note2
2	Low Power Output 6	User Defined Low Power Outputs (Positive or Negative 2.4A) *Note2
3	Low Power Output 7	User Defined Low Power Outputs (Positive or Negative 2.4A) *Note2
4	Low Power Output 8	User Defined Low Power Outputs (Positive or Negative 2.4A) *Note2

Note 2 : all low power outputs when placed in drive low mode have a 800 μ A quiescent current. This may cause false triggering in very light loads. This can be remedied by placing a 1k Ω resistor across the load.

3.1.7) Connector C - Aux Connector

Pin	Name	Function
1	Radio In +	Positive input for Radio re-broadcast
2	CAN1 H	CAN bus High connection
3	CAN1 L	CAN bus Low connection
4	External Reset	Positive switched Reset input
5	Universal Input 2	User defined input (pull-up or pull-down through 8.2k Ω or analogue)
6	Universal Input 4	User defined input (pull-up or pull-down through 8.2k Ω or analogue)
7	Universal Input 6	User defined input (pull-up or pull-down through 10k Ω or analogue)
8	Radio In -	Negative input for Radio re-broadcast
9	Ground	Chassis
10	Supply Output (Fused)	Supply feed through for external devices (4A Fused)
11	External Standby	Negative switched Standby input
12	Universal Input 1	User defined input (pull-up or pull-down through 8.2k Ω or analogue)
13	Universal Input 3	User defined input (pull-up or pull-down through 8.2k Ω or analogue)
14	Universal Input 5	User defined input (pull-up or pull-down through 10k Ω or analogue)

3.1.8) HANDSET/CAN1 - System Connector

Pin	Name	Function
1	CAN1L	CAN bus Low connection (CAN-FD)
2	CAN1H	CAN bus High connection (CAN-FD)
3	MIC-	Negative Microphone input signal
4	Supply	Supply feed through for handsets (1A Fused)
5	Ground	Chassis
6	MIC+	Positive Microphone input signal
7	NC	No connect
8	PTT	Push to Talk

3.1.9) CAN3\RS485 Connector

Pin	Name	Function
1	CAN3H\RS485A	CAN3 High (CAN-FD) or RS485A connection
2	No Connection	-
3	CAN3L\RS485B	CAN3 Low (CAN-FD) or RS485B connection

3.1.10) USB-C (Micro Rev1)

Used with the MCS Configurator for programming the device

<http://mheupdate.blob.core.windows.net/mcsnx-config-update/mcsnx-config-install.exe>

3.1.11) CAN2 Connector

Pin	Name	Function
1	CAN2H	CAN2 High (CAN-FD)
2	No Connection	-
3	CAN2L	CAN2 Low (CAN-FD)

3.1.12) RST - Reset Button

Button for resetting of the unit.

3.1.13) SEL - Select Button

Button for selecting what information is displayed by the LEDs on the unit. Also used to force the unit into bootloader mode.

3.1.14) DIP SELECT - CAN Termination

Switch	Name	Function
1	CAN3 Termination	Activates a termination resistor on CAN bus 3 (120Ω)
2	CAN2 Termination	Activates a termination resistor on CAN bus 2 (120Ω)
3	CAN1 Termination	Activates a termination resistor on CAN bus 1 (120Ω)

3.1.15) SD – SD card slot

SD Card slot for insertion of an SD.

5.1) **Version History**

Version	Changes	Responsible Person(s)	Date
1V0	Initial document release	KJVR	2022/05/10
1V1	Added no connections for the CAN connectors	KJVR	2022/05/12
1V2	Updated the connectors	KJVR	2025/01/10
1V3	Updated dimensional drawings and render	KJVR	2025/01/21